

HIGHBIO - INTERREG NORD
2008 - 2011



EUROPEAN UNION
European Regional Development Fund

Högförädlade bioenergiprodukter via förgasning
Korkeasti jalostettuja bioenergiatuotteita kaasutuksen kautta
Refining of Novel Products by Biomass Gasification

Recent advances in FT-research at Chydenius

Henrik Romar

Piteå 18.5.2011



Content

1. Recent advances in Fisher-Tropsch
2. Tar collection
Some experiences of tar collection

Future experiments (from last seminar in Ylivieska)

- FTS on real syngas in the near future
- New equipment for gas analysis (CO, H₂, N₂ and C1-C5) after reactor in order to measure conversion rate is needed
- Analysis of tar-content in real syngas will be performed

HIGHBIO - INTERREG NORD
2008 - 2011



Högförädlade bioenergiprodukter via förgasning
Korkeasti jalostettuja bioenergiainotteita kaasutuksen kautta
Refining of Novel Products by Biomass Gasification

EUROPEAN UNION
European Regional Development Fund


Advances in FTS



Catalysts used in our research

- Metals
Co Ru
Fe Ru
- Carriers
Al₂O₃ pelleted
Al₂O₃ 100-150 μm, 240 m²/g
Al₂O₃-SiO₂ 60-40 50-100 μm
500 m²/g
- Precursors
Co(NO₃)₂ * 6H₂O
Fe(NO₃)₂
Ru(NO)(NO₃)₃
Co(Ac)₂

Particle size of the carrier affects catalytical activity and selectivity



Deugd et al., Trends in Fischer-Tropsch reactor technology-opportunities for structured reactors, *Topics in Catalysis*, vol.26, 2003, p.29-39

Modifications on the catalyst preparation (1)

Dry impregnation :

- Carrier is dried
- Precursor is dissolved in a small volume of water
Volume = pore volume + 10%
- Dry carrier is impregnated, the whole volume is used
- Dry impregnation gives a higher metal content compared to incipient wetness technique?
- Some problems with small particle carriers $\text{Al}_2\text{O}_3\text{-SiO}_2$

Modifications on the catalyst preparation (2)

- **Calcination:**

We have used a lower calcination temperature than previous, performed in a stream of air

- Previous: High temperature in ambient atmosphere
- Precursors are modified to MeO on the surface of the carrier

- **Reduction**, performed in reactor

We are using a lower reduction temperature than previous.



H₂ flow 25 ml/min

Metallic catalyst

Results


- More metal is introduced into the carrier?
 - Most likely but not confirmed yet
- Higher activity
 - More hydrocarbons are formed
 - Catalyst has to be more diluted
 - More heat is produced
 - With $\text{Al}_2\text{O}_3\text{-SiO}_2$: more compounds containing double bonds are formed

Reactions



$$\Delta H_r = -165 \text{ kJ/mol} \rightarrow \text{exothermic}$$

File :C:\msdchem\1\DATA\Fischer-Tropsch\20100319 ALOSIO 2-CO RU.D
Operator : hr
Acquired : 25 Mar 2010 10:13 using AcqMethod Diesel.M
Instrument : 5975_Demo
Sample Name :
Misc Info :
Vial Number: 1



Tests with "near real syngas"

- A gas with known composition was used as feed for the FT-synthesis
- This composition is close to real syngas, the H_2/CO is 1

Gas	Mol %
H_2	20
CO	20
CO_2	10
CH_4	1,5
N_2	Make up gas (48,5%)

Tests with "near real syngas"

- This "syngas" was tested with two different catalysts
 - CoRu on Al_2O_3 and CoRu on $\text{Al}_2\text{O}_3\text{-SiO}_2$
 - With the syngas we were able to have a slightly higher pressure than in previous runs
 - In both cases catalysts were active and produced hydrocarbons for 3 days
 - Beside liquid hydrocarbons a big amount of solid and semi-solid waxes was formed with CoRu on Al_2O_3

HIGHBIO - INTERREG NORD
2008 - 2011



Högförädlade bioenergiprodukter via förgasning
Korkeasti jalostettuja bioenergiatuotteita kaasutuksen kautta
Refining of Novel Products by Biomass Gasification

EUROPEAN UNION
European Regional Development Fund

Tar measurements from gasifiers





Tar measurement


- In order to collect tar compounds a sampling system system has been built
- Some preliminary tests have been made on real gas from the Sievi gasifier

Tar sampling system

- consists of
 - sampling probe (heated)
 - filter for particulates
 - moisture collector, (heated)
 - absorption bottles filled with iso-propanol
 - equipment to measure gasflow, sampling time, gas pressure and temperature



The newer version of the protocol




Results

- The sampling equipment is under optimisation
 - We know that (heavy?) tars condensate in the sampling line
 - Results are by no means quantitative
- Results are preliminary
 - We have found the compounds one can expect to see in producer gas
 - So far nothing can be said about concentrations

GC-MS chromatogram, tars

File : C:\msdchem\1\DATA\Fischer-Tropsch\SIEVIN TERVAT20102903.D
Operator :
Acquired : 6 Apr 2010 13:16 using AcqMethod tervat.M
Instrument : 5975_Demo
Sample Name :
Misc Info :
Vial Number: 1



Future experiments (from last seminar in Ylivieska)

- ✓ FTS on real syngas in the near future
- ✓ New equipment for gas analysis (CO, H₂, N₂ and C1-C5) after reactor in order to measure conversion rate is needed
- ✓ Analysis of tar-content in real syngas will be performed

HIGHBIO - INTERREG NORD
2008 - 2011



Högförädlade bioenergi produkter via förgasning
Korkeasti jalostettuja bioenergi tuotteita kaasutuksen kautta
Refining of Novel Products by Biomass Gasification

EUROPEAN UNION
European Regional Development Fund

Thank You!

